

Testing a Negative Earth Zener Diode

Battery voltage **MUST** exceed
12.75 volts for zener diode
to allow current flow

